



Figure 2.

\* Power switch and fuse are not included in the installation kit. The fuse can be any value from 1.25 Amp to 10 Amp. The NMEA IN and MOB cables are not included in the MK8 standard package.